

Island	TP Grid Bus name	Participant Responsible for metering	Substation
S	ABY0111	TPNZ	Albury
S	ADD0111	TPNZ	Addington
S	ADD0661	TPNZ	Addington
N	ALB0331	TPNZ	Albany
N	ALB1101	TPNZ	Albany
S	APS0111	TPNZ	Arthur's Pass
N	ARA2201	MRPL	Aratiatia
S	ARG1101	TPNZ	Argyle
N	ARI1101	MRPL	Arapuni
S	ASB0331	TPNZ	Ashburton
S	ASB0661	TPNZ	Ashburton
S	ASY0111	TPNZ	Ashley
N	ATI2201	MRPL	Atiamuri
S	AVI2201	MERI	Aviemore
S	BAL0331	TPNZ	Balclutha
S	BDE0111	TPNZ	Brydone
S	BEN0162	MERI	Benmore
S	BEN0163	MERI	Benmore
S	BLN0331	TPNZ	Blenheim
N	BOB0331	TPNZ	Bombay
N	BOB1101	TPNZ	Pukekohe
N	BPE0331	TPNZ	Bunnythorpe
N	BPE0551	TPNZ	Bunnythorpe
S	BPT1101	TPNZ	Black Point
N	BRB0331	TPNZ	Bream Bay
N	BRK0331	TPNZ	Brunswick
S	BRY0111	TPNZ	Bromley
S	BRY0661	TPNZ	Bromley
S	BWK1101	TPNZ	Berwick
N	CBG0111	TPNZ	Cambridge
S	CLH0111	TPNZ	Castle Hill
S	CML0331	TPNZ	Cromwell
S	COB0661	ONRG	Cobb
S	COL0111	TPNZ	Coleridge
S	COL0661	TRUS	Coleridge
N	CPK0111	TPNZ	Central Park
N	CPK0331	TPNZ	Central Park
N	CST0111	TPNZ	Carrington Street
N	CST0331	TPNZ	Carrington Street
S	CUL0331	TPNZ	Culverden
S	CYD0331	CTCT	Clyde
S	CYD2201	CTCT	Clyde
N	DAR0111	TPNZ	Dargaville
S	DOB0331	TPNZ	Dobson
N	DVK0111	TPNZ	Dannevirke
N	EDG0331	TPNZ	Edgecumbe
S	EDN0331	TPNZ	Edendale
N	FHL0331	TPNZ	Fernhill
S	FKN0331	TPNZ	Frankton
N	GFD0331	TPNZ	Gracefield
N	GIS0501	TPNZ	Gisborne

Island	TP Grid Bus name	Participant Responsible for metering	Substation
N	GLN0331	TPNZ	Glenbrook
N	GLN0332	TPNZ	Glenbrook
S	GOR0331	TPNZ	Gore
S	GYM0661	TPNZ	Greymouth
N	GYT0331	TPNZ	Greytown
N	HAM0111	TPNZ	Hamilton
N	HAM0331	TPNZ	Hamilton
N	HAM0551	TPNZ	Hamilton
N	HAY0111	TPNZ	Haywards
N	HAY0331	TPNZ	Haywards
N	HEN0331	TPNZ	Henderson
N	HEP0331	TPNZ	Hepburn Road
N	HIN0331	TPNZ	Hinuera
S	HKK0661	TPNZ	Hokitika
N	HLY2201	GENE	Huntly
S	HOR0331	TPNZ	Hororata
S	HOR0661	TPNZ	Hororata
N	HTI0331	TPNZ	Hangatiki
N	HUI0331	TPNZ	Huirangi
N	HWA0331	TPNZ	Hawera
N	HWA1101	TPNZ	Hawera (Patea PS)
N	HWA1102	KIWI	Hawera(Whareroa)
S	HWB0331	TPNZ	Halfway Bush
S	HWB0332	TPNZ	Halfway Bush
S	INV0331	TPNZ	Invercargill
S	INV0331	TPCO	Invercargill
S	INV0331	ELIN	Invercargill
S	ISL0331	TPNZ	Islington
S	ISL0661	TPNZ	Islington
S	KAI0111	TPNZ	Kaiapoi
N	KAW0111	TPNZ	Kawerau
N	KAW0112	TPNZ	Kawerau
N	KAW0113	TPNZ	Kawerau
N	KEN0331	TPNZ	Kensington
S	KIK0111	TPNZ	Kikiwa
N	KIN0111	TPNZ	Kinleith
N	KIN0112	TPNZ	Kinleith
N	KIN0331	TPNZ	Kinleith
S	KKA0331	TPNZ	Kaikoura
N	KOE0331	TPNZ	Kaikohe
N	KPA1101	TPNZ	Kaponga
N	KPO1101	MRPL	Karapiro
N	KPU0661	TPNZ	Kopu
N	KTA0331	TPNZ	Kaitaia
S	KUM0661	TPNZ	Kumara
N	KWA0111	TPNZ	Kaiwharawhara
N	LFD1101	TPNZ	Lichfield
N	LFD1102	TPNZ	Lichfield
N	LTN0331	TPNZ	Linton
S	MAN2201	MERI	Manapouri
N	MA11101	TPNZ	Matahina

Island	TP Grid Bus name	Participant Responsible for metering	Substation
N	MAT1101	TRUS	Matahina
S	MCH0111	TPNZ	Murchison
N	MDN0141	MRPL	Marsden A
N	MDN0142	MRPL	Marsden A
N	MDN1101	MRPL	Marsden B
N	MER0331	TPNZ	Bombay
N	MGM0331	TPNZ	Mangamaire
N	MHO0331	TPNZ	Mangahao
N	MHO0331	TODD	Mangahao
N	MLG0111	TPNZ	Melling
N	MLG0331	TPNZ	Melling
N	MNG0331	TPNZ	Mangere
N	MNG1101	TPNZ	Mangere
N	MNI0111	TPNZ	Motunui
S	MOT0111	TPNZ	Motueka
N	MPE0331	TPNZ	Maungatapere
S	MPI0661	TPNZ	Motupipi
N	MRA0111	TPNZ	Moturoa
N	MST0331	TPNZ	Masterton
N	MST0331	GENE	Masterton
N	MTI2201	MRPL	Maraetai
N	MTM0111	TPNZ	Mt. Maunganui
N	MTM0331	TPNZ	Mt. Maunganui
N	MTN0331	TPNZ	Marton
N	MTO0331	TPNZ	Maungaturoto
N	MTR0331	TPNZ	Mataroa
S	NMA0331	TPNZ	North Makarewa
N	NPK0331	TPNZ	National Park
N	NPL0331	CTCT	New Plymouth
S	NSY0331	TPNZ	Naseby
S	OAM0331	TPNZ	Oamaru
S	OHA2201	MERI	Ohau A
S	OHB2201	MERI	Ohau B
S	OHC2201	MERI	Ohau C
N	OHK2201	MRPL	Ohakuri
N	OKI0111	TPNZ	Ohaaki
N	OKI2201	CTCT	Ohaaki
N	OKN0111	TPNZ	Ohakune
N	ONG0331	TPNZ	Ongarue
N	OPK0331	TPNZ	Opunake
S	ORO1101	TPNZ	Orowaiti
S	ORO1102	TPNZ	Orowaiti
N	OTA0221	TPNZ	Otahuhu
N	OTA1101	CTCT	Otahuhu A
N	OTA2202	CTCT	Otahuhu B
S	OTI0111	TPNZ	Otira
N	OWH0111	TPNZ	Owhata
N	PAK0331	TPNZ	Pakuranga
S	PAL0331	TPNZ	Palmerston
S	PAP0111	TPNZ	Papanui
S	PAP0661	TPNZ	Papanui

Island	TP Grid Bus name	Participant Responsible for metering	Substation
N	PEN0221	TPNZ	Penrose
N	PEN0331	TPNZ	Penrose
N	PEN1101	TPNZ	Penrose
N	PNI0331	TPNZ	Pauatahanui
N	PPI2201	CTCT	Poihipi
N	PRM0331	TPNZ	Paraparaumu
N	RDF0331	TPNZ	Redclyffe
S	RFN1101	TPNZ	Reefton
S	RFN1102	TPNZ	Reefton
N	ROS0221	TPNZ	Mt Roskill
N	ROS1101	TPNZ	Mt Roskill
N	ROT0111	TPNZ	Rotorua
N	ROT0331	TPNZ	Rotorua
N	ROT1101	TPNZ	Rotorua
S	ROX1101	CTCT	Roxburgh PS
S	ROX2201	CTCT	Roxburgh PS
N	RPO2201	GENE	Rangipo
S	SBK0331	TPNZ	Southbrook
S	SDN0331	TPNZ	South Dunedin
N	SFD0331	TPNZ	Stratford
N	SFD0331	CTCT	Stratford
N	SFD2201	NGC	Stratford
S	SPN0331	TPNZ	Springston
S	STK0331	TPNZ	Stoke
S	STU0111	TPNZ	Studholme
N	SVL0331	TPNZ	Silverdale
N	SWN2201	MRPL	Southdown
N	TAK0331	TPNZ	Takanini
N	TGA0111	TPNZ	Tauranga
N	TGA0331	TPNZ	Tauranga
S	TIM0111	TPNZ	Timaru
S	TKA0111	MERI	Tekapo A
S	TKA0331	TPNZ	Tekapo A
S	TKB2201	MERI	Tekapo B
N	TKH0111	TPNZ	Te Kaha
N	TKR0331	TPNZ	Takapu Road
N	TKU0331	TPNZ	Tokaanu
N	TKU2201	GENE	Tokaanu
N	TMI0331	TPNZ	Te Matai
S	TMK0331	TPNZ	Temuka
N	TMN0551	TPNZ	Taumarunui
N	TMU0111	TPNZ	Te Awamutu
N	TMU1101	GENE	Te Awamutu
N	TNG0111	TPNZ	Tangiwai
N	TNG0551	TPNZ	Tangiwai
N	TRK0111	TPNZ	Tarukenga
N	TUI0111	TPNZ	Tuai
N	TUI1101	GENE	Tuai
N	TWH0331	TPNZ	Te Kowhai
S	TWI2201	TPNZ	Tiwai Point
S	TWZ0331	TPNZ	Twizel

Island	TP Grid Bus name	Participant Responsible for metering	Substation
N	UHT0331	TPNZ	Upper Hutt
N	WAI0111	TPNZ	Waiotahi
N	WDV0111	TPNZ	Woodville
N	WDV1101	MERI	Te Apiti
N	WEL0331	TPNZ	Wellsford
N	WES0331	TPNZ	Western Road
N	WGN0331	TPNZ	Wanganui
N	WHI0111	TPNZ	Whirinaki
N	WHI0111	CTCT	Whirinaki
N	WHU0331	TPNZ	Waihou
N	WIL0331	TPNZ	Wilton
N	WIR0331	TPNZ	Wiri
N	WKM2201	TUAR	Whakamaru
N	WKM2201	MRPL	Whakamaru
N	WKO0331	TPNZ	Waikino
N	WMG0331	TPNZ	Waimangaroa
N	WPA2201	MRPL	Waipapa
S	WPR0331	TPNZ	Waipara
N	WPT0111	TPNZ	Westport
N	WPW0331	TPNZ	Waipawa
N	WRA0111	TPNZ	Wairoa
N	WRK0331	TPNZ	Wairakei
N	WRK2201	CTCT	Wairakei
S	WTK0111	MERI	Waitaki
S	WTK0331	TPNZ	Waitaki
N	WTU0331	TPNZ	Whakatu
N	WVY0111	TPNZ	Waverley